



ResMed AirView™



Global



Americas



EMEA



Download Raw Data Signals

Description:

You can view or download data signals from a patient's record.

To download raw data signals:

1. Open a patient's record from the **Diagnostic patients** list.
2. From the **Diagnostic** tab, click **Raw data signals** in the Recording panel.
3. From the bottom right of the data signals screen, click **Download HST raw data**.
4. Click **Save** in the record Download dialog box and then select a location folder.
5. Click **Save** to start downloading